

DS-PS PRESSURE SENSITIVE CARPET SEAMING TAPE

Read Complete Instructions Prior To Installation:

INSTRUCTIONS

1. Floor must be dry, clean and free of dust, dirt, and debris.
2. Cut lengths of DS-PS Tape to the perimeter of the room.
 - a. Cut strips in addition to the perimeter strips, as necessary, to adhere carpet to the floor— approximately two to three feet parallel spacing.
 - b. Peel off white paper liner from non-reinforced side of DS-PS tape (non-reinforced side to floor, reinforced scrim side to carpet) and adhere tape to the floor using hand or foot pressure. Position carpet in room, aligning the seam (if present) as necessary.
3. If seams are present, cut carpet edges perfectly straight for the best seam. Use seam sealer on both cut edges to prevent raveling and delamination. Allow seam sealer to dry 8-10 minutes.
4. Position the carpet and seam edges (butted together) in their final location. Use a pen or pencil to mark a line down the center of the seam onto the floor.
5. Roll or fold the seam edges back, and using the line as the center, apply a length of DS-PS Tape on the floor using hand or foot pressure.
6. Place the carpet edges back over the tape to assure proper alignment. Make any final adjustment at this point.
7. Roll or fold the seam edges back, remove top release liner from the full seam length, and drop one edge onto the tape. Now, press it down into the adhesive. Drop the second edge onto the tape, taking care to carefully position the second edge so it is butted against the first edge. Work in short sections for best results. *Note: May be advantageous to start from center and work outward.*
8. Carefully fold the carpet back around the remaining areas of the room. Remove the remaining top liner and place the carpet, assuring no wrinkles or fullness are present out to the perimeter walls.